



P.O. Box 32, Pismo Beach, CA., 93448
parkpets.com * Ph.805-434-2305 * Fax 805-434-2369

Park Pets Installation using Unitary Tile or Pour-in-Place Rubber Fall Material

- REMOVE THE PARK PET FROM ITS PALLET BY UNBOLTING THE SECURING BOLTS ON THE BOTTOM.
- REMOVE THE FOUR (4) ANCHOR BOLTS (J-BOLTS) THAT ARE TAPED TO THE PALLET AND SET OFF TO THE SIDE.
- YOU SHOULD HAVE A COPY OF THE "ILLUSTRATED" INSTALLATION GUIDE. IF NOT, YOU CAN EASILY DOWNLOAD ONE FROM OUR WEB-SITE.
- CONFIRM THE DESIGNATED LOCATION FOR THE PARK PET.
- SCREW ALL FOUR ANCHOR BOLTS INTO THE FOUR RECIEVERS LOCATED UNDERNEATH THE BOTTOM SIDE OF THE PARK PET.
- SET THE PET IN THE DESIRED LOCATION, MAKE SURE THAT YOUR BASE MATERIAL IS STABLE, AND ALL USE-ZONE CRITERIA IS MET.
- ORIENTATE THE PET ON THE LOCATION FOR INSTALLATION. MARK THE BASE MATERIAL OR CONCRETE WHERE THE FOUR ANCHOR BOLTS MAKE CONTACT. THIS "MARK" IS WHERE THE CENTER OF YOUR ANCHOR HOLES ARE LOCATED!
- SET THE PET OFF TO THE SIDE. NOTE: FOR AN EXISTING CONCRETE SLAB INSTALLATION, YOU WILL DRILL FOUR (4) HOLES @ 1-INCH DIAMETER AND FULL DEPTH OF CONCRETE. FILL THESE HOLES 3/4 FULL WITH A HILTI-150 TWO-PART EPOXY OR "EQUAL" AND GENTLY LOWER THE PET INTO POSITION ALLOWING THE FOUR BOLTS TO ENTER THE HOLES UNTIL THE PET NOW REST AT ITS DESIRED LOCATION. LET SET FOR 24 HOURS BEFOR INSTALLING FALL MATERIAL.
- ON A SOIL OR BASE INSTALLATION; DIG HOLES AT "MARKED" LOCATIONS AS SPECIFIED ON INSTALLATION ILLUSTRATION, FILL HOLES WITH WET CONCRETE, FOLLOWED BY RE-POSITIONING PARK PET WITH ANCHOR BOLTS INTO WET CONCRETE. LET SET UNDISTURBED FOR 48 HOURS BEFORE BACK-FILLING WITH FALL MATERIAL. IF DONE CORRECTLY, TOP OF FALL MATERIAL SHOULD LIE A FEW INCHES ABOVE THE BOTTOM OF THE PARK PET.
- NEVER INSTALL PARK PETS ON TOP OF FALL MATERIAL. FALL MATERIAL SHOULD ALWAYS BE INSTALLED AFTER PARK PET INSTALLATION.

"All Park Pets and Boulders MUST be installed with the resilient "safety" surfacing appropriate to the playground safety guidelines for your city, county, or state."